1-0166 208cc Engine (Non-Gen) WITH ROLL OVER VALVE-PLMHK14650124PBCKPTUV46E2M

VENDOR: LCT

MODEL: PLMHK14650124PBCKPTUV46E2M


DRAWN BY: RSW

DATE: 12/03/12

For parts Call 888-279-9274



Model # will be



PARTS LIST

Ref #		Otv	MiTMPN	LCTPN
1	CYLINDER HEAD ASSEMBLY	Qiy 1	SERVICE	
- 1		-	SERVICE	SK2081000.
	CYLINDER HEAD, MACHINED GASKET,CYLINDER HEAD	1		
	PUSH ROD GUIDE PLATE	1		
	PUSH ROD INTAKE VALVE	1		
	EXHAUST VALVE VALVE SPRINGS	1		
		2		
	BOLT (M8X55)	4		
	IN.VALVE SPRING RETAINER	1		
	EX.VALVE SPRING RETAINER	1		
	VALVE LASH CAP	1		
	TAPPET	2		
	PIVOT BOLT, ROCKER	2		
	ROCKER ARM NUT	2		
	ROCKER ARM	2		
	ROCKER ARM PIVOT	2		
	VALVE COVER GASKET	1		
2	PUSH ROD ASSEMBLY	1	SERVICE	SK2081001
	PUSH ROD GUIDE PLATE	1		
	PUSH ROD	2		
	VALVE COVER GASKET	1		
3	VALVE COVER ASSEMBLY	1	45-0449	SK2084501
	COVER, VALVE	1		
	VALVE COVER GASKET	1		
	HOSE, BREATHER	1		
4	CYLINDER ROD ASSEMBLY	1	SERVICE	SK2081305
	CYLINDER, MACHINED	1		
	RADIAL BALL BEARING(52.5*25.5*15mm)	1		
	OIL SEAL (FLYWHEEL) (25.5*41.25*6mm)	1		
	DRAIN PLUG BOLT	2		
	DRAIN PLUG WASHER	2		
	DOWEL PIN 10X16	2		
	DOWEL PIN 8X14	2		
	GOVERNOR GEAR ASSEMBLY	1		
	GOVERNOR ARM PADDLE	1		
	LOCK PIN, GOV ARM PADDLE	1		
	WASHER, GOVERNOR ARM PADDLE	1		
	LOW OIL SENSOR	1		
	LOW OIL SENSOR BOLT	2		
		1		
	ILOW OIL SENSOR NOT	1 1		
	LOW OIL SENSOR NUT			
5			SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY	1	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED	1 1	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED PISTON PIN	1 1 1	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED PISTON PIN PISTON PIN CLIP	1 1 1 2	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED PISTON PIN PISTON PIN CLIP FIRST RING SET,PISTON	1 1 1 2	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED PISTON PIN PISTON PIN CLIP FIRST RING SET,PISTON SECOND RING SET,PISTON	1 1 1 2 1	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED PISTON PIN PISTON PIN CLIP FIRST RING SET,PISTON SECOND RING SET,PISTON THIRD RING SET,PISTON	1 1 1 2 1 1	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED PISTON PIN PISTON PIN CLIP FIRST RING SET,PISTON SECOND RING SET,PISTON THIRD RING SET,PISTON CONNECTION ROD, MACHINED	1 1 1 2 1 1 1	SERVICE	SK2081400
5	PISTON AND ROD ASSEMBLY PISTON, MACHINED PISTON PIN PISTON PIN CLIP FIRST RING SET,PISTON SECOND RING SET,PISTON THIRD RING SET,PISTON	1 1 1 2 1 1	SERVICE	SK2081400

6	CONNECTING ROD ASSEMBLY	1	SERVICE	SK2081500.1
	CONNECTION ROD, MACHINED	1		
	CAP, CONNECTING ROD	1		
	CONNECTION ROD BOLT	2		
7	CAMSHAFT SYSTEM ASSEMBLY	1	SERVICE	SK2081600.1
	CAMSHAFT SYSTEM ASSY	1		
				_
8	FLYWHEEL ASSEMBLY	1	45-0450	SK2081710.1
	FLYWHEEL ASSEMBLY	1		
9	COOLING FAN, FLYWHEEL	1	45-0391	SK2084000.1
	COOLING FAN, FLYWHEEL	1		
		•	•	
10	CRANKSHAFT ASSEMBLY (KEYED)	1	SERVICE	SK2081800.1
	FLYWHEEL NUT	1		
	SPECIAL WOODRUFF KEY	1		
	TIMING MASTER GEAR	1		
	SPEED REGULATING DRIVE GEAR	1		
	CRANKSHAFT MACHINING, KEYED	1		
<u></u>			l	
11	AIR FILTER ASSEMBLY	1	45-0451	SK2082004.1
• •	COVER, AIR FILTER, PANEL	1	10 0 10 1	ORZOGZOG III
	BASE, AIR FILTER, PANEL	1		
	FILTER ELEMENT, PANEL PAPER	1		
	FOAM PRE-FILTER	1		
	INTAKE BACKFIRE PLATE	1		
	INTAKE BAOKI IKE I LATE	<u> </u>		
12	FILTER ELEMENT PAPER	1	45-0136	SK2082012.1
12	FILTER ELEMENT, PAPER	1	40 0100	CR2002012.1
	THE TEXT ELEMENT, I AN EX		<u> </u>	
13	CALIFORNIA MUFFLER	1	45-0392	SK2089000.1
- 10	MUFFLER, SQUARE	1	10 0002	CITEOGOGGII
	GASKET, EX MAN-CYLINDER HEAD (STAINLESS STEEL)	1		
	SHIELD, MUFFLER	1		
	BOLT, MUFFLER SHIELD	4		
		4		
		1		
	EXHAUST STUD LOCKING TAB	1		
	WASHER (BLACK) 6MM	4		
11	WASHER (BLACK) 6MM	4	45,0452	SK2082242.4
14	WASHER (BLACK) 6MM FUEL TANK	4	45-0452	SK2082212.1
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL	1 1	45-0452	SK2082212.1
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator)	1 1 1	45-0452	SK2082212.1
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE	1 1 1 1 2	45-0452	SK2082212.1
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK	1 1 1 2	45-0452	SK2082212.1
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER	1 1 1 2 1	45-0452	SK2082212.1
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER GASKET, CAP	1 1 1 2 1 1	45-0452	SK2082212.1
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER	1 1 1 2 1	45-0452	SK2082212.1
	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER GASKET, CAP CAP, TANK	1 1 1 2 1 1 1		
14	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER GASKET, CAP CAP, TANK FUEL PETCOCK	1 1 1 2 1 1 1 1	45-0452 45-0164	SK2082212.1 SK2082221.1
	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER GASKET, CAP CAP, TANK	1 1 1 2 1 1 1		
15	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER GASKET, CAP CAP, TANK FUEL PETCOCK FUEL PETCOCK FUEL PETCOCK	1 1 1 2 1 1 1 1	45-0164	SK2082221.1
	WASHER (BLACK) 6MM FUEL TANK FUEL TANK, METAL FUEL HOSE (Non Generator) CLIP, FUEL HOSE FUEL PETCOCK FUEL STRAINER GASKET, CAP CAP, TANK FUEL PETCOCK	1 1 1 2 1 1 1 1		

	CARBURETOR	1	45-0140	SK2082401.1
	CARBURETOR ASSEMBLY	1		
	CHOKE LEVER,CARBURETOR	1		
	GASKET,SPACER/CYLINDER HEAD	1		
	CARBURETOR SPACER	1		
	CARBURETOR GASKET, CARB/SPACER	1		
	CARBURETOR GASKET, CARB/AC	1		
	CARBONETON GAGNET, GARBIAG			
18	IGNITION COIL ASSEMBLY	1	45-0453	SK2082570.1
	IGNITION COIL ASSY	1		
	SPARK PLUG BOOT	1		
	10.7 max 1200 200 .			ı
20	SPARK PLUG	1	45-0142	SK2083810.1
	SPARK PLUG	1		
				I
21	ON/OFF SWITCH	1	45-0143	SK2082600.1
	ENGINE STOP SWITCH	1		
22	FLYWHEEL SHIELD	1	45-0454	SK2081760.1
	FLYWHEEL SHIELD	1	.3 0 10 1	21
	I LIVINELL OFFICES			
23	FUEL HOSE KIT	1	45-0399	SK2086000.1
	FUEL HOSE (Non Generator)	1	10 0000	O I I Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z Z
	CLIP, FUEL HOSE	2		
	0211,1 02211002			<u>l</u>
24	THROTTLE CONTROL ASSEMBLY	1	45-0148	SK2082800.1
	THROTTLE CONTROL ASSEMBLY	1	70 0 7 10	
				<u>I</u>
25	GOVERNOR GEAR ASSEMBLY	1	SERVICE	SK2082900.1
	GOVERNOR GEAR	1		
	GOVERNOR WEIGHT PIN			
	IGOVERNOR WEIGHT FIN	2		
	GOVERNOR SHAFT	1		
	GOVERNOR SHAFT	1		
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP	1		
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP	1 1 1		
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT	1 1 1 2		
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM	1 1 1 2		
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM	1 1 1 2	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER	1 1 1 2 1	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY	1 1 1 2 1 1	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM	1 1 1 2 1 1	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING	1 1 1 2 1 1 1	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING	1 1 2 1 1 1	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT	1 1 2 1 1 1 1 1 1	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm)	1 1 1 2 1 1 1 1 1 1	45-0154	SK2083000.1
26	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm)	1 1 1 2 1 1 1 1 1 1	45-0154 SERVICE	SK2083000.1
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM SHAFT ASSEMBLY GOVERNOR ARM PADDLE	1 1 2 1 1 1 1 1 1 1		
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM	1 1 2 1 1 1 1 1 1 1 1		
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM SHAFT ASSEMBLY GOVERNOR ARM PADDLE	1 1 2 1 1 1 1 1 1 1 1 1		
27	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM WSHAFT ASSEMBLY GOVERNOR ARM PADDLE WASHER, GOVERNOR ARM PADDLE	1 1 1 2 1 1 1 1 1 1 1 1		
	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM WSHAFT ASSEMBLY GOVERNOR ARM PADDLE WASHER, GOVERNOR ARM PADDLE	1 1 1 2 1 1 1 1 1 1 1 1		
27	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM HOLDER GOVERNOR ARM SHAFT ASSEMBLY GOVERNOR ARM PADDLE WASHER, GOVERNOR ARM PADDLE LOCK PIN, GOV ARM PADDLE 8MM	1 1 1 2 1 1 1 1 1 1 1 1 1	SERVICE	SK2083100.1
27	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM SHAFT ASSEMBLY GOVERNOR ARM PADDLE WASHER, GOVERNOR ARM PADDLE LOCK PIN, GOV ARM PADDLE 8MM RECOIL STARTER ASSEMBLY WITH STARTER CUP	1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	SERVICE	SK2083100.1
27	GOVERNOR SHAFT GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM SHAFT ASSEMBLY GOVERNOR ARM PADDLE WASHER, GOVERNOR ARM PADDLE LOCK PIN, GOV ARM PADDLE 8MM RECOIL STARTER ASSEMBLY WITH STARTER CUP	1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	SERVICE	SK2083100.1
27	GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM GOVERNOR ARM RECOIL STARTER ASSEMBLY WITH STARTER CUP RECOIL STARTER (ROUND) & CUP NON-SLOTTED	1 1 1 2 1 1 1 1 1 1 1 1 1 1 1	SERVICE 45-0149	SK2083100.1 SK2083200.2
27	GOVERNOR HOLDER CLIP GOVERNOR HOLDER CLIP GOVERNOR WEIGHT W PLAIN WASHER 6MM GOVERNOR SLIDER GOVERNOR LINK ASSEMBLY LINKAGE, GOVERNOR ARM THROTTLE RETURN SPRING GOVERNOR SPRING GOVERNOR ARM BOLT FLANGE NUT, GOV ARM (6mm) GOVERNOR ARM GOVERNOR ARM SHAFT ASSEMBLY GOVERNOR ARM PADDLE WASHER, GOVERNOR ARM PADDLE LOCK PIN, GOV ARM PADDLE 8MM RECOIL STARTER ASSEMBLY WITH STARTER CUP RECOIL STARTER (ROUND) & CUP NON-SLOTTED	1 1 1 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1	SERVICE 45-0149	SK2083100.1 SK2083200.2

ı	BLOWER HOUSING (BLACK)	1		
	DEOWER HOUSING (DEACK)		<u> </u>	1
31	CRANKCASE COVER ASSEMBLY	1	45-0395	SK2083600.1
<u> </u>	COVER, CRANKCASE	1	10 0000	0.12000001.
	GOVERNOR GEAR ASSEMBLY	1		
	RADIAL BALL BEARING(52.5*25.5*15mm)	1		
	OIL SEAL (25.5*41.25*6mm)	1		
	GASKET, CRANKCASE COVER	1		
	CAP, NON-REMOVABLE OIL FILL ASSY	1		
	SMALL BLACK DIPSTICK	1		
				•
32	OIL SEAL KIT	1	45-0396	SK2083900.1
	OIL SEAL (25.5*41.25*6mm)	1		
		-		
34	SPARK PLUG BOOT	1	45-0144	SK2083800.1
	SPARK PLUG BOOT	1		
36	GASKET KIT	1	45-0152	SK2084300.1
	GASKET, VALVE COVER	1		
	GASKET,SPACER/CYLINDER HEAD	1		
	CARBURETOR GASKET, CARB/SPACER	1		
	CARBURETOR GASKET, CARB/AC	1		ļ
	GASKET, CRANKCASE COVER	1		
	GASKET, CYLINDER HEAD	1		
	GASKET, MUFFLER	1		
37	OIL DIPSTICK	1	45-0151	SK2083711.1
	SMALL BLACK DIPSTICK	2		
20	DOCKED ADM ACCEMBLY	1	OEDV/IOE	01/00044004
38	ROCKER ARM ASSEMBLY	1	SERVICE	SK2081100.1
38	PUSH ROD GUIDE PLATE	1	SERVICE	SK2081100.1
38	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT	1 2	SERVICE	SK2081100.1
38	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER	1 2 2	SERVICE	SK2081100.1
38	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT	1 2 2 2	SERVICE	SK2081100.1
38	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER	1 2 2	SERVICE	SK2081100.1
	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM	1 2 2 2 2		
38	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY	1 2 2 2	SERVICE 45-0165	SK2081100.1
	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM	1 2 2 2 2 2		
	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY	1 2 2 2 2 2	45-0165	
39	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER	1 2 2 2 2 2		SK2082120.1
39	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG	1 2 2 2 2 2 2	45-0165	SK2082120.1
39	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG	1 2 2 2 2 2 2	45-0165	SK2082120.1
39	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG	1 2 2 2 2 2 1 1 1	45-0165 45-0166	SK2082120.1 SK2083705.1
39	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER	1 2 2 2 2 2 1 1	45-0165 45-0166	SK2082120.1 SK2083705.1
39	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER	1 2 2 2 2 2 1 1	45-0165 45-0166	SK2082120.1 SK2083705.1
39 40 41	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167	SK2082120.1 SK2083705.1 SK2089001.1
39 40 41	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167	SK2082120.1 SK2083705.1 SK2089001.1
39 40 41	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167	SK2082120.1 SK2083705.1 SK2089001.1
39 40 41 43	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE BREATHER TUBE	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167 45-0456	SK2082120.1 SK2083705.1 SK2089001.1 SK2084510.1
39 40 41 43	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE OIL SENSOR ASSEMBLY	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167 45-0456	SK2082120.1 SK2083705.1 SK2089001.1 SK2084510.1
39 40 41 43	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE OIL SENSOR ASSEMBLY	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167 45-0456	SK2082120.1 SK2083705.1 SK2089001.1 SK2084510.1
39 40 41 43	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE BREATHER TUBE OIL SENSOR ASSEMBLY OIL SENSOR	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167 45-0456	SK2082120.1 SK2083705.1 SK2089001.1 SK2084510.1
39 40 41 43	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE BREATHER TUBE OIL SENSOR LOW OIL SHUTDOWN MODULE	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167 45-0456	SK2082120.1 SK2083705.1 SK2089001.1 SK2084510.1
39 40 41 43	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE BREATHER TUBE OIL SENSOR LOW OIL SHUTDOWN MODULE	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167 45-0456	SK2082120.1 SK2083705.1 SK2089001.1 SK2084510.1
39 40 41 43 44	PUSH ROD GUIDE PLATE ROCKER ARM PIVOT PIVOT BOLT, ROCKER ROCKER ARM NUT ROCKER ARM CHOKE LEVER ASSEMBLY CHOKE LEVER NON-REMOVABLE OIL PLUG NON-REMOVABLE OIL PLUG FOAM PRE-FILTER FOAM PRE-FILTER BREATHER TUBE BREATHER TUBE OIL SENSOR LOW OIL SHUTDOWN MODULE LOW OIL SHUTDOWN MODULE	1 2 2 2 2 2 1 1 1 1 1 1 1 1 1 1 1 1 1 1	45-0165 45-0166 45-0167 45-0456 45-0457	SK2082120.1 SK2083705.1 SK2089001.1 SK2084510.1 SK2082700.1

63	VAPOR HOSE ASSEMBLY	1	45-0459	SK4149017.1
	VAPOR HOSE	1		
	VAPOR HOSE CLAMP	2		
65	TAPPET KIT	1	SERVICE	SK2081005.1
	TAPPET	2		
70	CARBURETOR REPAIR KIT	1	45-0460	SK9900.1
	CARBURETOR REPAIR KIT	1		
72	MAXX SERIES DECAL/LABEL KIT	1	SERVICE	SK2085000.1
	MAXX SERIES DECAL/LABEL KIT	1		
75	ROLL OVER VALVE	1	45-0461	SK2082230.1
	ROLL OVER VALVE	1		
77	RECOIL BOLT KIT	1	45-0462	SK9999.1
	RECOIL BOLT	3		