


1-0194 Engine Parts



ITEM	DESCRIPTION	PART #	LCT #
1	CYLINDER HEAD ASSEMBLY	SERVICE	SK4141050
2	PUSH ROD ASSEMBLY	SERVICE	SK4141001
3	VALVE COVER ASSEMBLY	45-0233	SK4144500.1
4	CHOKE LEVER, CARBURETOR	45-0401	SK4142120
5	PISTON ASSEMBLY	SERVICE	SK4141400
6	CONNECTING ROD ASSEMBLY	SERVICE	SK4141500
7	ELECTRIC STARTER ASSEMBLY	45-0234	SK4148050
8A	FLYWHEEL ASSEMBLY	SERVICE	SK4141701
9	COOLING FAN, FLYWHEEL	45-0405	SK4144000
10	CRANKSHAFT ASSEMBLY (KEYED)	SERVICE	SK4141800
11	AIR FILTER ASSEMBLY PANEL	45-0181	SK4142002
12	FILTER ELEMENT PAPER	45-0182	SK4142012
13A	MUFFLER ASSEMBLY	45-0180	SK2912100
14C	FUEL TANK	45-0186	SK4142201
15	FUEL PETCOCK	45-0187	SK4142220
16A	FUEL CAP ASSEMBLY	45-0188	SK4148300
17	CARBURETOR SERVICE KIT	45-0224	SK4142400.1
18	IGNITION COIL ASSEMBLY	45-0225	SK4142500.1
19	CONTROL MODULE (CDI BOX)	45-0227	SK4142750.1
20	ON/OFF SWITCH	45-0143	SK2082600
21	NON-REMOVABLE OIL PLUG	45-0183	SK4143715
22	OIL DIPSTICK	45-0184	SK4143711
23	FUEL HOSE KIT	45-0189	SK4146000
24	THROTTLE CONTROL ASSEMBLY	SERVICE	SK4142800
25	GOVERNOR GEAR ASSEMBLY	SERVICE	SK4142900
26	GOVERNOR LINK ASSEMBLY	45-0228	SK4143000
27	GOVERNOR ARM SHAFT ASSEMBLY	SERVICE	SK4143100
28A	RECOIL STARTER ASSEMBLY	45-0229	SK4143200.1
29	STARTER CUP	SERVICE	SK4143300
30A	BLOWER HOUSING SERVICE KIT	45-0230	SK4143400.1
31	CRANKCASE COVER ASSEMBLY	SERVICE	SK4143600
32	OIL SEAL KIT	45-0406	SK4143905
34	SPARK PLUG BOOT	45-0231	SK4143800.1
36	GASKET KIT	45-0232	SK4144300.1
37	LOW OIL SENSOR	45-0226	SK4142700.1
38	COUNTER WEIGHT KIT	SERVICE	SK4141650
39	CAMSHAFT SYSTEM ASSEMBLY	SERVICE	SK4141600
41	SPARK PLUG	45-0179	SK2911550
42	TOP SHIELD	SERVICE	SK4141020
43	ROCKER ARM ASSEMBLY	SERVICE	SK4141100
44	CYLINDER ROD ASSEMBLY	SERVICE	SKSN4444
45	CHARGING COIL AC	45-0221	SKSN0770
47	FOAM PRE-FILTER	45-0185	SK4149001

For parts Call 888-279-9274

Mi-T-M Corporation

SCALE: NTS DATE: 8/17/12 DRAWING SIZE: B APPD: DRAWN BY: RSW

414cc ENGINE (ELECTRIC START)

DRAWING/PART NO:
1-0194