




ELITE Series™

Pressure Washer Lavador a Presión

Illustrated Parts List
Las Partes ilustradas Listan

**01806
(2650 PSI)**



Questions? Help is just a moment away!

Preguntas? La ayuda es justa un momento lejos!

Call: **Pressure Washer Helpline - 1-800-743-4115** M-F 8-5 CT


Llamada: **Lavador a Presión Helpline - 1-800-743-4115** M-F 8-5 CT

BRIGGS & STRATTON POWER PRODUCTS GROUP, LLC
JEFFERSON, WISCONSIN, U.S.A.



IPL No. 19311IGS
Revision 0 (04/08/2003)

EXPLODED VIEW AND PARTS LIST - MAIN UNIT




Item	Part #	Description	Item	Part #	Description
1	P190156GS	BASE	9	I92553GS	KIT,Vibration Mount
2	P187602GS	HANDLE	10	I90147GS	PUSHNUT
3	I92734GS	ASSY, Billboard	11	B5646GS	KIT, Spray Tip
4	I85877GS	HOSE	12	I92199GS	EXTENSION
5	I92134GS	KIT, Engine Mounting Hardware	13	I92526GS	KIT,Wheel
6	I92131GS	KIT, Pump Mounting Hardware	14	23139BGS	KEY
7	B3263GS	GUN	15	I93087GS	ASSY, Pump (see page 3)
8	I90668GS	KIT, Handle Fasteners	900	NSP	ENGINE

Items Not Illustrated:

Part #	Description
I91678GS	MANUAL, Owner's
I93111GS	MANUAL, Illustrated Parts List
I92795GS	KIT, Decals
BB3061BGS	OIL, Engine

EXPLODED VIEW AND PARTS LIST - PUMP



Item	Part #	Description
20	190638GS	PLUG
22	190639GS	SPACER
24	190640GS	WASHER
26	190641GS	PLUG
29	190642GS	HOSE TAIL
34	190643GS	JET
35	190644GS	SPRING
38	190645GS	INJECTOR, Detergent
42	190646GS	PISTON, Guide
48	190647GS	HOUSING
50	191441GS	VENT, CAP
64	193124GS	FLANGE
65	193125GS	BALL BEARING
67	190651GS	GRUB SCREW

Item	Part #	Description
68	190652GS	BALL
69	190653GS	SPRING
70	190654GS	PUMP HEAD
71	190655GS	GRUB SCREW & WASHER
72	190656GS	OIL BOTTLE
A	190657GS	KIT, CHECK VALVE
B	190658GS	KIT, PISTON SET
C	193129GS	KIT, SEAL OIL
D	190660GS	KIT, SEAL HIGH PRESSURE
E	190677GS	KIT, O-RINGS
F	193126GS	KIT, UNLOADER
G	193127GS	KIT, CAM & BEARING

NOTE: Item letters A - G are service kits and include all parts shown within the box.

NOTES