


PUMP ASSEMBLY (3-0212)



For parts Call 888-279-9274

3-0212 & 3-0213-060502-EDW

PUMP ASSEMBLY (3-0212)											
REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Valve Cap	39-0201	6	20	Low Pressure Seal (See 70-0317)	N/A Sep.	3	39	Lockwasher	N/A	6
2	Back-Up Ring	25-0509	6	21	Spacer	46-0907	3	40	Connecting Rod	46-0913	3
3	O-Ring	25-0386	6	22	Snap-Ring	46-0908	3	41	Plunger Rod	46-0915	3
4	Valve w/O-ring (See 70-0314)	N/A Sep.	6	23	Oil Seal	26-0242	3	42	Connecting Rod Pin	46-0914	3
5	Back-Up Ring	25-0516	6	24	Screw	27-8884	8	43	Slinger Washer	46-0916	3
6	O-ring	25-0515	6	25	Shaft Cover	N/A	1	44	Piston	46-0917	3
7	Manifold Pump	46-0900	1	26	O-ring	25-0512	2	45	Washer	28-1041	3
8	Lockwasher	29-0155	8	27	Oil Seal	26-0243	1	46	Screw	27-8965	3
9	Screw	27-8470	8	28	Bearing	48-0073	2	47	Oil Dipstick	39-0204	1
10	O-ring	25-0372	1	29	Key	43-0091	1	48	Spring Retainer	46-0924	1
11	Plug	39-0202	1	30	Crankshaft	N/A	1	49	Reflector Pump	46-0925	1
12	O-ring	25-0510	3	31	Crankcase	46-0911	1	50	Oil Sight	46-0926	1
13	Plug	39-0203	2	32	Screw	27-8888	6	51	O-ring	25-0514	1
14	Support Ring (See 70-0317)	N/A Sep.	3	33	Crankcase Cover (Inc. 35-37)	46-0912	1	52	Shim	46-0947	1
15	High Pressure Seal (See 70-0317)	N/A Sep.	3	34	O-ring	25-0513	1	53	Support Bearing Cover (Inc. 48-51)	46-0918	1
16	Low Pressure Seal (See 70-0317)	N/A Sep.	3	35	O-ring	25-0370	1		Valve Kit (Inc. 6 each 4-6)	70-0314	1
17	Piston Guide	46-0904	3	36	Oil Sight Glass	46-0670	1		Water Seals Kit (Inc. 3 each 14-16, 18-20)	70-0317	1
18	O-ring (See 70-0317)	N/A Sep.	3	37	Spring Retainer	46-0671	1				
19	Back-Up Ring (See 70-0317)	N/A Sep.	3	38	Screw	N/A	6				