


PUMP ASSEMBLY (3-0260)



For parts Call 888-279-9274

3-0260-051404-DLG

PUMP ASSEMBLY (3-0260)								
REF. #	DESCRIPTION	PART #	QTY.		REF. #	DESCRIPTION	PART #	QTY.
1	Unloader Stack Assembly	8-0550	1		24	Low Pressure Seal	46-0727	3
2	Valve Cap	39-0087	3		25	Retainer Ring	46-0872	3
3	O-ring	25-0160	3		26	Spacer	46-0892	3
4	Single Valve Assembly (See 70-0383)	N/A Sep.	3		27	Seal	26-0239	3
5	Plug	39-0096	2		28	O-ring	25-0502	1
6	O-ring	25-0387	2		29	Screw	27-8432	4
7	Manifold	46-1126	1		30	Case	*CF	1
8	Bolt	27-8960	3		31	O-ring	25-0386	1
9	Lockwasher	29-0055	3		32	Plug	39-0203	1
10	O-ring	25-0406	1		33	Spring	49-0142	3
11	Check Valve	8-0518	1		34	Piston	46-0897	3
12	Spring	49-0124	1		35	Spring Retainer	46-0875	3
13	O-ring	25-0407	1		36	Washer	46-0876	1
14	O-ring	25-0159	1		37	Bearing	48-0057	1
15	Detergent Injector	46-1127	1		38	Washer	48-0056	1
16	Hose Barb	46-0869	1		39	Shaft	46-1106	1
17	O-ring	25-0371	1		40	Bearing	48-0083	1
18	Ball (See 70-0293)	N/A Sep.	1		41	Oil Seal	26-0279	1
19	Spring (See 70-0293)	N/A Sep.	1		42	O-ring	25-0503	1
20	Single Valve Assembly (See 70-0383)	N/A Sep.	3		43	Flange	38-0064	1
21	High Pressure Seal (See 70-0384)	N/A Sep.	3			Valve Kit (Inc. 3 each 4, 20)	70-0383	
22	Packing Retainer	46-1128	3			High Pressure Seals Kit (Inc. 3 each 21, 23-26)	70-0384	
23	O-ring	25-0501	3			Injector Repair Kit (Inc. 17-19)	70-0293	
*Consult Factory								