


PUMP ASSEMBLY (3-0261)



3-0261-122007-JJT

PUMP ASSEMBLY (3-0261)											
REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Valve Plug	46-1203	3	21	Low Pressure Seal (See 70-0434)	N/A Sep.	3	41	O-ring	25-0339	1
2	Backup Ring	25-0592	3	22	O-ring	25-0015	3	42	Bolt	27-8435	6
3	O-ring	25-0139	6	23	Low Pressure Seal Retainer (See 70-0434)	N/A Sep.	3	43	Lockwasher	29-1014	1
4	Cap	46-1206	3	24	Oil Seal	26-0047	3	44	Connecting Rod	46-1211	3
5	Valve Assembly (See 70-0431)	N/A Sep.	6	25	Bushing	9-0029	3	45	Piston Rod	46-1213	3
6	Guide	46-1205	3	26	O-ring	25-0052	1	46	Slinger Washer	46-1214	3
7	O-ring	25-0160	3	27	Bolt	27-8431	4	47	Plunger	46-1215	3
8	Backup Ring	25-0430	3	28	Oil Seal	26-0049	1	48	O-ring	25-0310	3
9	Spacer	46-1204	3	29	Crankcase Open Cover	46-1217	1	49	Bolt	46-1216	3
10	O-ring	25-0130	3	30	O-ring	25-0590	2	50	Oil Dipstick	46-0144	1
11	Backup Ring	25-0591	3	31	Bearing	46-0085	2	51	Crankcase	46-1209	1
12	Bolt	27-8073	8	32	Key	46-0602	1	52	Crankcase Sightglass Cover	46-1208	1
13	Lockwasher	29-0155	8	33	Crankshaft	46-1210	1	53	O-ring	25-0060	1
14	Manifold	46-1202	1	34	Connecting Rod Pin	43-0118	3	54	Sightglass	46-0574	1
15	Washer	28-1038	1	35	O-ring	25-0014	1	55	Sightglass Cover	46-1207	1
16	Hex Plug	39-0019	1	36	Hex Plug	39-0017	1	56	Bolt	27-8433	4
17	Washer	28-1002	1	37	Bolt	27-8812	4		Oil Seal Kit (Inc. 3 each 24)	70-0432	
18	Hex Plug	39-0018	2	38	Sight Glass	46-1163	1		Valve Kit (Inc. 6 each 5)	70-0431	
19	High Pressure Seal Assembly (See 70-0434)	N/A Sep.	3	39	O-ring	25-0059	1		Low/High Pressure Seals (Inc. 3 each 19, 21)	70-0433	
20	High Pressure Intermediate Seal Retainer (See 70-0434)	N/A Sep.	3	40	Crankcase Cover	46-1212	1		Packing Kit (Inc. 1 each 19-23)	70-0434	

Call for Parts 888-279-9274