


PUMP ASSEMBLY 3-0387



For parts Call 888-279-9274

3-0387 022813 JDK			
PUMP ASSEMBLY			
ITEM	DESCRIPTION	PART #	QTY
1	LOCKNUT	30-8152	1
2	WASHER	28-0054	1
3	UNLOADER KNOB	7-0241	1
4	SET SCREW	8-0479	1
5	KIT - UNLOADER RE-BUILD (INC. 6 O-RINGS)	70-0618	1
6	O-RING	25-0668	2
7	UNLOADER SEAT	46-1514	1
8	VALVE CAP	39-0250	3
9	O-RING	25-0665	6
10	KIT - VALVES	70-0613	6
11	HEAT DUMP VALVE	22-0408	1
12	BOLT	27-9603	4
13	INLET NUT	46-1515	1
14	INLET CONNECTOR	46-1516	1
15	FILTER	19-0001	1
16	O-RING	25-0671	2
17	KIT - DISCHARGE VALVE	70-0615	1
18	O-RING	25-0640	1
19	OUTLET ORIFICE	N/A	1
20	O-RING	25-0639	1
21	OUTLET NIPPLE	46-1517	1
22	KIT - PACKINGS	70-0616	3
23	RETAINER	46-1518	3
24	OIL SEAL	26-0388	3
25	SPRING	49-0170	3
26	PISTON	46-1511	3
27	SPRING RETAINER	46-1526	3
28	OIL SEAL	26-0386	1
29	BOLT	27-8433	4
30	FLANGE	46-1512	1
31	GASKET	26-0387	1
32	O-RING	25-0667	1
33	BEARING	N/A	1
34	CAM	N/A	1
35	BEARING	N/A	1
36	KIT - UNLOADER ASSEMBLY	70-0612	1
37	KIT - CHEMICAL INJECTOR	70-0614	1
38	KIT - OIL VENT CAP	70-0617	1
39	PLUG	46-1519	3
40	CLIP RING	46-1513	3
41	O-RING	25-0670	3