


PUMP ASSEMBLY (3-0393)



Pump Parts 888-279-9274

PUMP ASSEMBLY (3-0393)

3-0393 021819 JVA							
PUMP ASSEMBLY							
ITEM	DESCRIPTION	PART #	QTY	ITEM	DESCRIPTION	PART #	QTY
1	MANIFOLD	N/A	1	27	BOLT	27-8404	5
2	BOLT	27-8185	8	28	COVER/CRANKCASE	46-0295	1
3	FLATWASHER	28-1039	8	29	INDICATOR/OIL LEVEL	46-0114	1
4	O-RING (SEE KIT 70-0009)	25-0053	6	30	PLUG/HEX	39-0017	1
5	VALVE SEAT (SEE KIT 70-0009)	SEE KIT	6	31	O-RING	25-0014	4
6	VALVE PLATE (SEE KIT 70-0009)	SEE KIT	6	32	BOLT	27-8435	6
7	VALVE SPRING (SEE KIT 70-0009)	SEE KIT	6	33	LOCKWASHER	29-0154	6
8	VALVE CAGE (SEE KIT 70-0009)	SEE KIT	6	34	SLINGER WASHER	46-0146	3
9	O-RING	25-0012	6	35	PLUNGER	46-0052	3
10	VALVE PLUG- BRASS	46-0889	6	36	BACK UP RING	46-0109	3
11	VALVE ASSEMBLY (4 - 8)	22-0056	6	37	WASHER/GASKET	28-0400	3
12	BOLT	27-8431	8	38	BOLT/PISTON	46-0069	3
13	COVER/CRANKCASE CLOSED	46-0336	1	39	COVER/CRANKCASE OPEN	46-0296	1
14	O-RING	25-0013	2	40	SHIM	46-0113	1
15	BEARING	48-0012	2	41	SEAL/OIL	26-0049	1
16	SEAL/OIL	26-0047	3	42	O-RING	25-0015	3
17	BUSHING/BEARING	9-0029	3	43	LOW PRESSURE SEAL RETAINER	46-0057	3
18	CRANKCASE	46-0047	1	44	HIGH PRESSURE V-PACKING (SEE KIT 70-0147 OR 852-0122)	26-0098	3
19	OIL DIPSTICK	46-0144	1	45	HIGH PRESSURE HEAD RING (SEE KIT 70-0030 OR 852-0122)	46-0059	3
20	O-RING/COVER	25-0339	1	46	HIGH PRESSURE SEAL (SEE KIT 70-0148)	46-0659	3
21	CRANKSHAFT	46-0888	1	47	V-PACKING SUPPORT (SEE KIT 70-0147 OR 70-0148 OR 852-0122)	25-0207	3
22	RETAINING RING	46-0103	6	48	PLUG/HEX	39-0019	1
23	KEY	43-0048	1	49	WASHER	28-1038	1
24	PIN/CONNECTING ROD	43-0032	3	50	PLUG/HEX	39-0018	1
25	PISTON ROD	46-0056	3	51	WASHER	28-1002	1
26	CONNECTING ROD	46-0051	3	52	LOW PRESSURE SEAL (SEE KIT 70-0147 OR 852-0122)	26-0197	3

REPLACEMENT KITS				
KIT #	DESCRIPTION	ITEMS	# OF ASSEMBLIES	# OF CYLINDERS
70-0009	KIT - VALVE	4,5,6,7,8	6,6,6,6,6	3
70-0030	KIT - HEAD RING	45	6	3
70-0147	KIT - PACKING	44,47,52	3,3,3	3
70-0148	KIT - INTERMEDIATE RETAINER	46,47	3,3	3
852-0122	KIT - PACKING ASSEMBLY	44,45,47,52	3,3,3,3	3