


UNLOADER ASSEMBLY (8-0625)



Call for Parts 888-279-9274

UNLOADER ASSEMBLY

ITEM	DESCRIPTION	PART #	QTY		ITEM	DESCRIPTION	PART #	QTY
1	PLASTIC CAP	46-1461	1		23	O-RING	25-0255	1
2	BUSHING	46-1462	1		24	BALL	N/A	1
3	LOCKNUT	30-5018	1		25	SPRING	N/A	1
4	KNOB	7-0232	1		26	BANJO BOLT	8-0516	1
5	WASHER	28-0067	1		27	O-RING	25-0388	1
6	SPRING	N/A	1		28	HOSE BARB	46-0869	1
7	NUT	30-6024	2		29	O-RING	25-0371	1
8	PISTON GUIDE	N/A	1		30	BALL	8-0521	1
9	O-RING	25-0644	1		31	SPRING	8-0520	1
10	O-RING	25-0407	2		32	O-RING	25-0519	1
11	SPACER	N/A	1		33	PLUG	39-0363	1
12	O-RING	25-0502	1		34	BY-PASS HOUSING	N/A	1
13	O-RING	N/A	1		35	O-RING	25-0389	1
14	O-RING	25-0404	1		36	BANJO BOLT	8-0517	1
15	O-RING	25-0209	1		37	O-RING	25-0646	1
16	PLUG	39-0097	1		38	NON-RETURN VALVE	46-1249	1
17	VALVE HOUSING	N/A	1		39	SPRING	49-0167	1
18	O-RING	25-0370	1		40	ORIFICE	46-1250	1
19	O-RING	25-0527	1		41	O-RING	25-0500	1
20	THREADED PISTON	N/A	1		42	O-RING	25-0596	1
21	PIN	43-0139	1		43	DETERGENT INJECTOR	46-1251	1
22	SEAT	N/A	1			O-RING REPAIR KIT (INC. 9, 10, 12, 13, 15, 18, 19, 23, 27, 29, 32, 35, 37, 41, 42)	70-0583	

Call for Parts 888-279-9274