

8-0665 010522 JRC



8-0665 010522 JRC			
UNLOADER ASSEMBLY			
ITEM	DESCRIPTION	PART #	QTY
1	SHUTTER COUPLING	N/A	1
2	O-RING (SEE KIT 70-0750)	25-0159	2
3	SPRING	49-0180	1
4	SHUTTER PIN	8-0674	1
5	O-RING (SEE KIT 70-0750)	25-0375	1
6	WASHER	8-0427	2
7	BANJO BOLT	8-0675	1
8	VALVE HOUSING - BRASS	N/A	1
9	O-RING	25-0376	1
10	MANIFOLD FITTING	N/A	1
11	WASHER	28-1052	2
12	MANIFOLD	8-0676	1
13	BOLT	8-0677	1
14	O-RING (SEE KIT 70-0750)	SEE KIT	1
15	BRASS REST (SEE KIT 70-0750)	SEE KIT	1
16	O-RING (SEE KIT 70-0750)	25-0190	1
17	SPACER RING	N/A	1
18	BACK-UP RING (SEE KIT 70-0750)	SEE KIT	1
19	O-RING (SEE KIT 70-0750)	SEE KIT	1
20	PISTON HOLDER	N/A	1
21	BRASS LOCKNUT	N/A	1
22	BRASS PISTON	N/A	1
23	O-RING (SEE KIT 70-0750)	25-0205	1
24	BACK-UP RING (SEE KIT 70-0750)	8-0660	1
25	SPRING RETAINER	8-0421	1
26	SPRING	49-0181	1
27	ADJUSTING CAP	39-0092	1
28	CHEMICAL INJECTOR HOUSING (SEE KIT 852-0195)	46-1869	1
29	NOZZLE	N/A	1
30	SPRING (SEE KIT 852-0195)	49-0166	1
31	BALL (SEE KIT 852-0195)	50-0199	1
32	O-RING (SEE KIT 852-0195)	25-0645	1
34	BRASS COUPLING (SEE KIT 70-0582)	SEE KIT	1
35	SPRING (SEE KIT 70-0582)	49-0182	1
36	O-RING (SEE KIT 70-0582)	25-0157	1
37	HOSE BARB BRASS W/O-RING (SEE KIT 70-0582)	SEE KIT	1
38	INJECTOR KNOB (SEE KIT 70-0582)	SEE KIT	1
39	KIT/REGULATOR AND HOSE BARB (SEE KIT 852-0195)	70-0582	1
40	KNOB	7-0289	1
41	O-RING	N/A	1
42	SEAT	N/A	1
43	SET SCREW	8-0479	1
KIT	REGULATOR AND HOSE BARB (INC. 34-38)	70-0582	1
KIT	REPAIR KIT (INC. 2, 5, 14, 15, 16, 18, 19, 23, 24)	70-0750	1
KIT	CHEMICAL INJECTOR (28, 30, 31, 32, 39)	852-0195	1