



Performance Under Pressure

TECHNICAL PARTS LIST FOR ***CBA-3004-0MHB***

Engine Oil Grade:	SAE 10W-30
Engine Oil Capacity:	37 oz.
Pump Oil Grade:	Mi-T-M Pump Oil #AW-4085-0016
Pump Oil Capacity:	15 oz.
Nozzle Size:	4.0

This Parts Listing has been compiled for your benefit. You can be assured your Mi-T-M Cold Water Pressure Washer was constructed and designed with quality and performance in mind using over 25 years experience in the pressure washer business. Each component has been rigorously tested to insure the highest level of acceptance.

The contents of this Parts Listing are based on the latest product information available at the time of publication. Mi-T-M reserves the right to make changes in price, color, materials, equipment, specifications or models at any time without notice.

WARNING

THIS IS A PROFESSIONAL HIGH PRESSURE, COLD WATER PRESSURE WASHER. CAUTION SHOULD BE OBSERVED WHEN USING OR REPAIRING THIS UNIT! READ AND FOLLOW THE SAFETY WARNINGS LISTED BELOW BEFORE ATTEMPTING ANY REPAIRS ON THIS PRESSURE WASHER!

SAFETY WARNINGS

- 1. NEVER alter or modify the equipment. Be sure any accessory items and system components being used will withstand the pressure developed. Use only genuine Mi-T-M parts for repair of your pressure washer. Failure to do so can cause hazardous operating conditions and will VOID warranty.
- 2. NEVER make adjustments on machinery while the unit is connected to the engine without first removing the ignition cables from the spark plugs. Turning over the machinery by hand during adjustment or cleaning might start the machinery, causing serious injury to the operator.
- 3. Know how to stop and bleed pressures quickly. Be thoroughly familiar with controls.
- 4. Before servicing the unit, turn unit off, relieve the water pressure and allow the unit to cool down. Do not make repairs while the unit is running. Service in a clean, dry, flat area.
- 5. After testing the machine, DO NOT leave the pressurized unit unattended. Shut off the unit and release trapped pressure before leaving.

Table of Contents

SPECIFICATIONS.....3

NOTES4-5

FRAME ASSEMBLY (BEFORE SERIAL #10202373).....6

FRAME ASSEMBLY (AFTER SERIAL #10202373).....8

FRAME ASSEMBLY (AFTER SERIAL #10239171).....10

PUMP ASSEMBLY (3-0176)12

PUMP ASSEMBLY (3-0268)14

UNLOADER ASSEMBLY (8-0533)16

GUN ASSEMBLY (16-0001)18

SPECIFICATIONS

MODEL NUMBER	CBA-3004-0MHB
Operating Pressure (PSI/Bar):	3000 / 206.8
High Pressure Nozzle:	4.0
Water Volume (GPM/lpm):	3.5 / 13.2
Engine:	Honda
Horsepower	11.0
Engine Type	4 Stroke, Overhead Valve, Single Cylinder
Oil Type	SAE 10W 30
Oil Capacity (oz./liters)	37 / 1.1
Low Oil Protection	Oil Alert™
Fuel Type	Unleaded Gasoline 86 Octane Minimum
Fuel Capacity (gallon/ liters)	1.7 / 6.5
Starting	Recoil
Maximum No Load RPM	3600
Pump:	Belt Driven, Oil Bath, Triplex Piston
Oil Type	Mi-T-M Pump Oil #AW-4085-0016
Oil Capacity (oz./liters)	15 / .44
Plungers	Ceramic
Manifold	Forged Brass
Valves	Stainless Steel
Unloader	Adjustable
Thermal Relief Valve	Relieves heated water during unloader bypass stage
Unit Net Weight (Lbs/kg)	150 / 68
Unit Shipping Weight (Lbs/kg)	204 / 92.5
Unit Net Dimension (In/cm)	46.5L x 28W x 27.5H / 118L x 71W x 70H
Unit Shipping Dimension (In/cm)	48L x 30W x 34H / 122L x 76W x 86H

NOTES

SERIAL BREAK NUMBER:

#10202373

SERIAL BREAK EXPLANATION:


PUMP CHANGE FROM 3-0176 TO 3-0268. UNLOADER CHANGE FROM 8-0456 TO 8-0533.

#10239171

AXLE CHANGE.


NOTES

FRAME ASSEMBLY (BEFORE SERIAL #10202373)



FRAME ASSEMBLY (BEFORE SERIAL #10202373)											
REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY
1	Key	43-0078	1	25	Flatwasher	28-0023	9	48	Nozzle- 1504	18-0029	1
2	Decal- Warning: Risk of Burns (See 34-9017)	N/A Sep.	1	26	Tension Bracket	21-0218	2	-	Nozzle- 2504	18-0030	1
3	Decal- Caution: Risk of Fire (See 34-9017)	N/A Sep.	1	27	Bolt	27-0066	2	-	Nozzle- 4004	18-0031	1
4	Engine- Honda 11 HP	1-0039	1	28	Inlet Filter	19-0206	1	49	Grommet	33-0001	5
5	Decal- Data Plate	N/A	1	29	O-ring	25-0123	2	50	Decal- Mi-T-M Small Logo	62-0086	1
6	Locknut	30-0157	24	30	Quick Connect Socket	17-0004	2	51	Decal- White Die Cut 3000PSI	34-0775	1
7	Isolation Plate	5-0223	1	31	Thermal Relief Valve	22-0005	1	52	Decal- Mi-T-M Stripe	34-0502	1
8	Isolator	14-0097	4	32	Key w/ Pump	43-0091	1	53	Decal- Nozzles 0, 15, 25, 40	34-0500	1
9	Washer	28-0022	6	33	Pump	3-0176	1	54	Bushing	9-0017	1
10	Bolt	27-9524	7	34	Bolt	27-0121	4	55	Sheave	10-0035	1
11	Rear Handle	7-0183	1	35	Locknut	30-0159	4	56	Gun/Wand Assembly (Inc. 57-62)	851-0095	1
12	Bolt	27-0067	12	36	Beltguard Back	6-0106	1	57	Quick Connect Plug	17-0005	1
13	Bushing	62-0175	2	37	Edging *(Two Feet Required)	33-0433	1	58	Trigger Gun	16-0001	1
14	Axle	20-0819	1	38	Decal- Warning/Caution (See 34-9017)	N/A Sep.	1	59	Wand Grip	7-0002	1
15	Spacer	62-0189	4	39	Decal- Warning: Beltguard in Place (See 34-9017)	N/A Sep.	1	60	Wand	16-0120A01	1
16	Washer	28-0008	4	40	Drive Belt	11-0031	2	61	Decal- Warning: Risk of Injection (See 34-9017)	N/A Sep.	1
17	Wheel	14-0006	2	41	Sheave	10-0074	1	62	Quick Connect Socket	17-0001	1
18	Collar / Shaft	33-0351	2	42	Bushing	9-0005	1	63	O-ring	25-0122	1
19	Baseplate	5-0222	1	43	Bolt	27-0015	4	64	Hose Assembly (Inc. 30, 65, 66)	851-0007	1
20	Support Bracket	56-0054	1	44	Edging *(Four Feet Required)	33-0433	1	65	Quick Connect Plug	17-0006	1
21	Isolator	14-0008	2	45	Beltguard Cover	6-0107	1	66	Hose	15-0003	1
22	Bolt	27-0068	2	46	Bolt	27-8898	2		Safety Decal Kit (Inc. 2-3, 38-39, 47, 61)	34-9017	
23	Front Handle	7-018201	1	47	Decal- Operation (See 34-9017)	N/A Sep.	1	*Must Order in One Foot Lengths			
24	Bolt	27-0576	1	48	Nozzle- 0004	18-0028	1				


FRAME ASSEMBLY (AFTER SERIAL #10202373)



FRAME ASSEMBLY (AFTER SERIAL #10202373)

REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY
1	Key	43-0078	1	25	Flatwasher	28-0023	9	49	Decal- Operation (See 34-9017)	N/A Sep.	1
2	Decal- Warning: Risk of Burns (See 34-9017)	N/A Sep.	1	26	Tension Bracket	21-0218	1	50	Nozzle- 0004	18-0028	1
3	Decal- Caution: Risk of Fire (See 34-9017)	N/A Sep.	1	27	Tension Bracket	21-0220	1	-	Nozzle- 1504	18-0029	1
4	Engine- Honda 11 HP	1-0039	1	28	Bolt	27-0066	2	-	Nozzle- 2504	18-0030	1
5	Decal- Data Plate	N/A	1	29	Inlet Filter	19-0206	1	-	Nozzle- 4004	18-0031	1
6	Locknut	30-0157	24	30	O-ring	25-0123	2	51	Grommet	33-0001	5
7	Isolation Plate	5-0223	1	31	Quick Connect Socket	17-0004	2	52	Decal- Mi-T-M Small Logo	62-0086	1
8	Isolator	14-0097	4	32	Thermal Relief Valve	22-0005	1	53	Decal- White Die Cut 3000PSI	34-0775	1
9	Washer	28-0022	6	33	Plug	23-0244	1	54	Decal- Mi-T-M Stripe	34-0502	1
10	Bolt	27-9524	7	34	Key w/ Pump	43-0091	1	55	Decal- Nozzles 0, 15, 25, 40	34-0500	1
11	Rear Handle	7-0183	1	35	Pump	3-0268	1	56	Bushing	9-0017	1
12	Bolt	27-0067	12	36	Bolt	27-0121	4	57	Sheave	10-0035	1
13	Bushing	62-0175	2	37	Locknut	30-0159	4	58	Gun/Wand Assembly (Inc. 59-64)	851-0095	1
14	Axle	20-0819	1	38	Beltguard Back	6-0106	1	59	Quick Connect Plug	17-0005	1
15	Spacer	62-0189	4	39	Edging *(Two Feet Required)	33-0433	1	60	Trigger Gun	16-0001	1
16	Washer	28-0008	4	40	Decal- Warning/Caution (See 34-9017)	N/A Sep.	1	61	Wand Grip	7-0002	1
17	Wheel	14-0006	2	41	Decal- Warning: Beltguard in Place (See 34-9017)	N/A Sep.	1	62	Wand	16-0120A01	1
18	Collar / Shaft	33-0351	2	42	Drive Belt	11-0031	2	63	Decal- Warning: Risk of Injection (See 34-9017)	N/A Sep.	1
19	Baseplate	5-0222	1	43	Sheave	10-0074	1	64	Quick Connect Socket	17-0001	1
20	Support Bracket	56-0054	1	44	Bushing	9-0005	1	65	O-ring	25-0122	1
21	Isolator	14-0008	2	45	Bolt	27-0015	4	66	Hose Assembly (Inc. 31, 67-68)	851-0007	1
22	Bolt	27-0068	2	46	Edging *(Four Feet Required)	33-0433	1	67	Quick Connect Plug	17-0006	1
23	Front Handle	7-018201	1	47	Beltguard Cover	6-0107	1	68	Hose	15-0003	1
24	Bolt	27-0576	1	48	Bolt	27-8898	2		Safety Decal Kit (Inc. 2-3, 40-41, 49, 63)	34-9017	
*Must Order in One Foot Lengths											

FRAME ASSEMBLY (AFTER SERIAL #10239171)




FRAME ASSEMBLY (AFTER SERIAL #10239171)

REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY	REF #	DESCRIPTION	PART #	QTY
1	Key	43-0078	1	24	Tension Bracket	21-0220	1	47	Nozzle- 0004	18-0028	1
2	Decal- Warning: Risk of Burns (See 34-9017)	N/A Sep.	1	25	Bolt	27-0066	2	-	Nozzle- 1504	18-0029	1
3	Decal- Caution: Risk of Fire (See 34-9017)	N/A Sep.	1	26	Inlet Filter	19-0206	1	-	Nozzle- 2504	18-0030	1
4	Engine- Honda 11 HP	1-0039	1	27	O-ring	25-0123	2	-	Nozzle- 4004	18-0031	1
5	Decal- Data Plate	N/A	1	28	Quick Connect Socket	17-0004	2	48	Grommet	33-0001	5
6	Locknut	30-0157	28	29	Thermal Relief Valve	22-0005	1	49	Decal- Mi-T-M Small Logo	62-0086	1
7	Isolation Plate	5-0223	1	30	Plug	23-0244	1	50	Decal- White Die Cut 3000PSI	34-0775	1
8	Isolator	14-0097	4	31	Key w/ Pump	43-0091	1	51	Decal- Mi-T-M Stripe	34-0502	1
9	Washer	28-0022	8	32	Pump	3-0268	1	52	Decal- Nozzles 0, 15, 25, 40	34-0500	1
10	Bolt	27-9524	7	33	Bolt	27-0121	4	53	Bushing	9-0017	1
11	Rear Handle	7-0183	1	34	Locknut	30-0159	4	54	Sheave	10-0035	1
12	Bolt	27-0067	16	35	Beltguard Back	6-0106	1	55	Gun/Wand Assembly (Inc. 55-61)	851-0095	1
13	Axle Bracket	20-0864A01	1	36	Edging *(Two Feet Required)	33-0433	1	56	Quick Connect Plug	17-0005	1
14	Jam Nut	30-0117	2	37	Decal- Warning/Caution (See 34-9017)	N/A Sep.	1	57	Trigger Gun	16-0001	1
15	Wheel	14-0006	2	38	Decal- Warning: Beltguard in Place (See 34-9017)	N/A Sep.	1	58	Wand Grip	7-0002	1
16	Baseplate	5-0222	1	39	Drive Belt	11-0031	2	59	Wand	16-0120A01	1
17	Support Bracket	56-0054	1	40	Sheave	10-0074	1	60	Decal- Warning: Risk of Injection (See 34-9017)	N/A Sep.	1
18	Isolator	14-0008	2	41	Bushing	9-0005	1	61	Quick Connect Socket	17-0001	1
19	Bolt	27-0068	2	42	Bolt	27-0015	4	62	O-ring	25-0122	1
20	Front Handle	7-018201	1	43	Edging *(Four Feet Required)	33-0433	1	63	Hose Assembly (Inc. 28, 64-65)	851-0007	1
21	Bolt	27-0576	1	44	Beltguard Cover	6-0107	1	64	Quick Connect Plug	17-0006	1
22	Flatwasher	28-0023	9	45	Bolt	27-8898	2	65	Hose	15-0003	1
23	Tension Bracket	21-0218	1	46	Decal- Operation (See 34-9017)	N/A Sep.	1		Safety Decal Kit (Inc. 2-3, 37, 38, 46, 60)	34-9017	

*Must Order in One Foot Lengths

PUMP ASSEMBLY (3-0176)




3-0176-010505-DLG

PUMP ASSEMBLY (3-0176)

REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Bolt	27-8884	8	30	Crankcase	46-0811	1	63	O-ring (See 8-0456)	N/A Sep.	1
2	Shaft Cover	46-0691	1	31	Oil Seal	46-0931	3	64	Back-up Ring (See 8-0456)	N/A Sep.	1
3	Oil Seal	26-0188	1	32	O-ring	25-0384	3	65	Poppet	8-0443	1
4	O-ring	25-0380	2	33	Low Pressure Seal (See 70-0177)	N/A Sep.	3	66	Pin	8-0444	1
5	Bearing	48-0072	2	34	Packing Retainer	46-0708	3	67	Spring Button	8-0445	1
-	Bearing (XRCA Series)	48-0061	2	35	V-Packing (See 70-0177)	N/A Sep.	3	68	Spring Guide	8-0474	1
6	Key	43-0091	1	36	Support Ring (See 70-0178)	N/A Sep.	3	69	Spring	49-0132	1
7	Crankshaft	46-1103	1	37	O-ring	25-0372	1	70	Spring Button	8-0475	1
-	Crankshaft (XRCA Series)	46-0692	1	38	Plug	39-0088	1	71	Adjustment Barrel	8-0476	1
8	Plug	39-0102	1	39	Plug	39-0086	1	72	Pin	8-0477	1
9	O-ring	25-0325	3	40	Manifold	46-0711	1	73	Unloader Knob	7-0141	1
10	Plug	39-0086	1	41	Valve Cap	39-0095	6	74	Nut	30-3025	1
11	Bolt	27-8885	6	42	O-ring	25-0160	6	75	Bolt	27-8433	1
12	Crankcase Cover	46-0719	1	43	Single Valve Assembly (Inc. 41-45) (See 70-0319)	N/A Sep.	6	76	Cap	7-0142	1
13	O-ring	25-0370	1	44	O-ring	25-0386	6	77	Adapter	8-0448	1
14	Oil Sight Glass	46-0670	1	45	Valve Seat (See 70-0319)	N/A Sep.	6	78	Washer	8-0449	1
15	Reflector	46-0824	1	46	Valve Plate (See 70-0319)	N/A Sep.	6	79	Washer	8-0450	1
16	Retainer	46-0671	1	47	Valve Spring (See 70-0319)	N/A Sep.	6	80	Unloader Body	8-0451	1
17	O-ring	25-0398	1	48	Valve Cage (See 70-0319)	N/A Sep.	6	81	O-ring	25-0391	1
18	Connecting Rod	46-0896	3	49	Plug	39-0096	2	82	Check Valve	8-0454	1
-	Connecting Rod (XRCA Series)	46-0696	3	50	O-ring	25-0387	2	83	Spring	49-0123	1
19	Piston Pin	46-0698	3	51	Bolt	27-8440	8	84	O-ring	25-0372	1
20	Plunger Rod	46-0699	3	52	Lockwasher	29-0154	8	85	Adaptor Nipple	24-0159	1
21	Washer	46-0700	3	53	Inlet Bypass Adapter	8-0437	1		High Pressure Seals Kit (Inc. 3 each 32, 33, 35)	70-0177	
22	Back-up Ring	25-0404	3	54	Washer	8-0440	1		Support Rings Kit (Inc. 3 each 36)	70-0178	
23	O-ring	25-0382	3	55	Adapter	8-0438	1		Valve Kit (Inc. 6 each 44-48)	70-0319	
24	Piston	46-0701	3	56	Washer	8-0439	1		Unloader Kit (Includes 53-83)	8-0456	
25	Gasket	26-0191	3	57	O-ring (See 8-0456)	N/A Sep.	1		Unloader Repair Kit (Inc. 57, 59, 61-64, 81)	70-0180	
26	Nut	30-6020	3	58	Nipple	8-0441	1		Piston Kit (Inc. 3 each 21-26)	70-0352	
27	Oil Dipstick	39-0090	1	59	O-ring (See 8-0456)	N/A Sep.	1		Oil Seals Kit (Inc. 3, 4, 17, 31)	70-0321	
28	Support Bearing Cap	46-0703	1	60	Piston	8-0442	1				
29	Shim- 0.1mm (Qty. Varies 1-3)	46-0704	-	61	Back-up Ring (See 8-0456)	N/A Sep.	2				
-	Shim- 0.2mm (Qty. Varies 1-3)	46-0705	-	62	O-ring	25-0371	5				


PUMP ASSEMBLY (3-0268)



PUMP ASSEMBLY (3-0268)

REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Screw	27-8884	8	18	Piston Pin	46-0698	3	35	O-ring	25-0386	6
2	Pump Shaft	46-0691	1	19	Plunger Rod	46-0699	3	36	Unloader	8-0533	1
3	Oil Seal	26-0188	1	20	Washer	46-0700	3	37	Lockwasher	29-0154	8
4	O-ring	25-0380	2	21	Back Ring	25-0404	3	38	Screw	27-8440	8
5	Bearing	48-0061	2	22	O-ring	25-0382	3	39	Manifold	46-1186	1
6	Crankshaft	46-1103	1	23	Piston	46-0701	3	40	Support Ring (See 70-0178)	N/A Sep.	3
7	Key	43-0091	1	24	Washer / Gasket	26-0191	3	41	V-Packing (See 70-0177)	N/A Sep.	3
8	Plug	39-0086	1	25	Nut	30-6020	3	42	Packing Retainer	46-0708	3
9	O-ring	25-0325	1	26	Oil Dipstick	39-0090	1	43	Low Pressure Seal (See 70-0177)	N/A Sep.	3
10	Screw	27-8885	6	27	Pump Crankcase	46-1198	1	44	O-ring	25-0384	3
11	Pump	46-0719	1	28	Bearing	46-0072	1	45	Oil Seal	46-0931	3
12	O-ring	25-0370	1	29	Shim - 0.2mm (Qty. vaires 1-3)	46-0705	1		High Pressure Seals Kit (Inc. 3 each 41, 43, 44)	70-0177	
13	Oil Sight Glass	46-0670	1	30	Shim - 0.1mm (Qty. vaires 1-3)	46-0704	1		Support Ring Kit (Inc. 3 each 40)	70-0178	
14	Oil Reflector	46-0824	1	31	Bearing Cap	46-0703	1		Valve Kit (Inc. 6 each 34, 35)	70-0319	
15	Spring Retainer	46-0671	1	32	Valve Cap	39-0095	6		Oil Seals Kit (Inc. 3, 4, 16, 45)	70-0321	
16	O-ring	25-0398	1	33	O-ring	25-0160	6		Piston Kit (Inc. 3 each 20-25)	70-0352	
17	Connecting Rod	46-0896	3	34	Complete Valve Assembly (See 70-0319)	N/A Sep.	6				

UNLOADER ASSEMBLY (8-0533)




8-0533-102104-JJF

UNLOADER ASSEMBLY (8-0533)

REF. #	DESCRIPTION	PART #	QTY.	REF. #	DESCRIPTION	PART #	QTY.
1	Unloader Cap	7-0142	1	17	Seat	8-0529	1
2	Screw	27-8433	1	18	O-ring	25-0527	1
3	Nut	30-3025	1	19	Bolt	8-0531	1
4	Unloader Knob	7-0141	1	20	O-ring	25-0388	2
5	Unloader	8-0476	1	21	Unloader Body	8-0530	1
6	Unloader Pin	8-0478	1	22	O-ring	25-0437	1
7	Spring Guide	8-0523	1	23	Adapter Nipple	24-0159	1
8	Upper Plate	8-0524	1	24	O-ring	25-0372	1
9	Unloader Spring	49-0132	1	25	Unloader Check Valve Spring	49-0123	1
10	Lower Plate	8-0525	1	26	Unloader Check Valve	8-0454	1
11	Piston	8-0526	1	27	O-ring	25-0528	1
12	O-ring	25-0526	2	28	O-ring	25-0519	1
13	Piston Guide	8-0527	1	29	Bypass Housing	8-0532	1
14	O-ring	25-0510	1	30	O-ring	25-0389	1
15	O-ring	25-0407	1	31	Bolt	8-0517	1
16	Bypass Jet	8-0528	1		Unloader Repair Kit (Inc. 12, 14-15, 18, 20, 22, 24, 27, 28, 30)	70-0341	

GUN ASSEMBLY (16-0001)



16-0001-110399-RD

GUN ASSEMBLY (16-0001)			
REF. #	DESCRIPTION	PART #	QTY.
1	Plastic Housing	16-0008	1
2	Screw	27-3230	2
3	Brass Housing	16-0012	1
4	Gun Repair Kit	70-0055	1
5	Brass Plug	39-0024	1
6	Plastic Cover	16-0009	1
7	Pipe Assembly	16-0013	1
8	Trigger Pin	16-0063	1
9	Trigger/Safety Lock-off	16-0010	1
10	Pipe Assembly- Inlet	16-0016	1
	Complete Gun Assembly	16-0001	1

Manufactured by Mi-T-M
8650 Enterprise Drive, Peosta IA 52068
563-556-7484/ Fax 563-556-1235