


**RYOBI**  
**18 Volt EZ-CLEAN Power Cleaner**  
**Item No. RY120350**  
**Mfg No. 090079483**  
**Replacement Parts List**

**TECHTRONIC INDUSTRIES POWER EQUIPMENT**

998000252  
4-29-20 (REV:01)

P.O. Box 1288, Anderson, SC 29622 USA  
1-800-860-4050 • [www.ryobitools.com](http://www.ryobitools.com)

RYOBI 18V EZ-CLEAN POWER CLEANER – ITEM NO. RY120350



**RYOBI 18V EZ-CLEAN POWER CLEANER – ITEM NO. RY120350**

The model number will be found on a label attached to the housing. Always mention the model number in all correspondence regarding your **POWER CLEANER** or when ordering parts.

**PARTS LIST**

<b>KEY NO.</b>	<b>PART NUMBER</b>	<b>DESCRIPTION</b>	<b>QTY</b>
1	308751017	Inlet Connector .....	1
2	570742189	O-Ring (ID11.3 x CS2.5) .....	1
3	308103009	Water Inlet Filter.....	1
4	308835112	Suction Hose Assembly .....	1
5	310448023	Lower Lance Assembly (With 3-in-1 Nozzle).....	1
6	310448024	Upper Lance Assembly .....	1
7	570742188	O-Ring Seal (ID142.5 x CS4) .....	1
8	527932016	Battery Door Latch .....	1
9	940657337	Danger Hangtag .....	1
10	940657336	Warning Label.....	1
		<b>NOT SHOWN:</b>	
	998000105	Operator's Manual	